

# How To Size Gusseted Poly Bags Covers And Liners

## How To Measure For Gusseted Pallet Covers

Add approximately 4" to either the width (W) or depth (D) for a loose fit.  
For length, add half of depth to actual length.

Example - a loaded pallet measures (W) 46" x (D) 49" x (L)50".

To properly size the pallet cover, you do the following -

$$(W) 46" + 4" = 50"$$

$$(D) 49" = 49"$$

$$(L) 50" + 25" = 75"$$

In this case, the size to order would be 50" x 49" x 75".